




HB-4100-LR

Exploded Diagram/Parts Breakdown



No	Description	Part No.
1	Ceramic Catridge	H41-001
2	Diaphragm Assembly	H41-002
3	Solenoid Assembly	H41-003
4	PCB / Sensor	H41-004
5	Supply Tube	H41-005
6	Filter Screen	H41-006
7	Battery Holder	H41-008

HYDROTEK INTERNATIONAL, INC.
5055 Forsyth Commerce Rd., Ste 124
Orlando, FL 32807
800.922.9883 (Phone)
866.670.5580 (Fax)
www.hydrotekintl.com

